

§ 254.4

leases or facilities. All the leases or facilities in your plan must have the same owner or operator (including affiliates) and must be located in the same MMS Region (see definition of Regional Response Plan in §254.6).

(b) Regional Response Plans must address all the elements required for a response plan in Subpart B, *Oil Spill Response Plans for Outer Continental Shelf Facilities*, or Subpart D, *Oil Spill Response Requirements for Facilities Located in State Waters Seaward of the Coast Line*, as appropriate.

(c) When developing a Regional Response Plan, you may group leases or facilities subject to the approval of the Regional Supervisor for the purposes of:

- (1) Calculating response times;
- (2) Determining quantities of response equipment;
- (3) Conducting oil-spill trajectory analyses;
- (4) Determining worst case discharge scenarios; and
- (5) Identifying areas of special economic and environmental importance that may be impacted and the strategies for their protection.

(d) The Regional Supervisor may specify how to address the elements of a Regional Response Plan. The Regional Supervisor also may require that Regional Response Plans contain additional information if necessary for compliance with appropriate laws and regulations.

§254.4 May I reference other documents in my response plan?

You may reference information contained in other readily accessible documents in your response plan. Examples of documents that you may reference are the National Contingency Plan (NCP), Area Contingency Plan (ACP), MMS environmental documents, and Oil Spill Removal Organization (OSRO) documents that are readily accessible to the Regional Supervisor. You must ensure that the Regional Supervisor possesses or is provided with copies of all OSRO documents you reference. You should contact the Regional Supervisor if you want to know whether a reference is acceptable.

30 CFR Ch. II (7-1-00 Edition)

§254.5 General response plan requirements.

(a) The response plan must provide for response to an oil spill from the facility. You must immediately carry out the provisions of the plan whenever there is a release of oil from the facility. You must also carry out the training, equipment testing, and periodic drills described in the plan, and these measures must be sufficient to ensure the safety of the facility and to mitigate or prevent a discharge or a substantial threat of a discharge.

(b) The plan must be consistent with the National Contingency Plan and the appropriate Area Contingency Plan(s).

(c) Nothing in this part relieves you from taking all appropriate actions necessary to immediately abate the source of a spill and remove any spills of oil.

(d) In addition to the requirements listed in this part, you must provide any other information the Regional Supervisor requires for compliance with appropriate laws and regulations.

§254.6 Definitions.

For the purposes of this part:

Adverse weather conditions means weather conditions found in the operating area that make it difficult for response equipment and personnel to clean up or remove spilled oil or hazardous substances. These include, but are not limited to: Fog, inhospitable water and air temperatures, wind, sea ice, current, and sea states. It does not refer to conditions such as a hurricane, under which it would be dangerous or impossible to respond to a spill.

Area Contingency Plan means an Area Contingency Plan prepared and published under section 311(j) of the Federal Water Pollution Control Act (FWPCA).

Coast line means the line of ordinary low water along that portion of the coast which is in direct contact with the open sea and the line marking the seaward limit of inland waters.

Discharge means any emission (other than natural seepage), intentional or unintentional, and includes, but is not limited to, spilling, leaking, pumping, pouring, emitting, emptying, or dumping.