Stage 2 noise levels mean the requirements for Stage 2 noise levels as defined in part 36 of this chapter in effect on November 5, 1990.

Stage 3 noise levels mean the requirements for Stage 3 noise levels as defined in part 36 of this chapter in effect on November 5, 1990.

Stage 4 noise level means a noise level at or below the Stage 4 noise limit prescribed in part 36 of this chapter.

Stage 2 airplane means a civil subsonic jet (turbojet) airplane with a maximum certificated weight of 75,000 pounds or more that complies with Stage 2 noise levels as defined in part 36 of this chapter.

Stage 3 airplane means a civil subsonic jet (turbojet) airplane with a maximum certificated weight of 75,000 pounds or more that complies with Stage 3 noise levels as defined in part 36 of this chapter.

Stage 4 airplane means an airplane that has been shown not to exceed the Stage 4 noise limit prescribed in part 36 of this chapter. A Stage 4 airplane complies with all of the noise operating rules of this part.

Stage 5 airplane means an airplane that has been shown not to exceed the Stage 5 noise limit prescribed in part 36 of this chapter. A Stage 5 airplane complies with all of the noise operating rules of this part.

Stage 5 noise level means a noise level at or below the Stage 5 noise limit prescribed in part 36 of this chapter.

[Doc. No. 26433, 56 FR 48658, Sept. 25, 1991, as amended by Amdt. 91–252, 61 FR 66185, Dec. 16, 1996; Amdt. 91–275, 67 FR 45237, July 8, 2002; Amdt. 91–288, 70 FR 38749, July 5, 2005; 72 FR 68475, Dec. 5, 2007; Docket FAA–2015–3782, Amdt. 91–349, 82 FR 46132, Oct. 4, 2017]

§91.853 Final compliance: Civil subsonic airplanes.

Except as provided in §91.873, after December 31, 1999, no person shall operate to or from any airport in the contiguous United States any airplane subject to §91.801(c), unless that airplane has been shown to comply with Stage 3, Stage 4, or Stage 5 noise levels

[Docket FAA-2015-3782, Amdt. 91-349, 82 FR 46132, Oct. 4, 2017]

§91.855 Entry and nonaddition rule.

No person may operate any airplane subject to §91.801(c) of this subpart to or from an airport in the contiguous United States unless one or more of the following apply:

- (a) The airplane complies with Stage 3, Stage 4, or Stage 5 noise levels.
- (b) The airplane complies with Stage 2 noise levels and was owned by a U.S. person on and since November 5, 1990. Stage 2 airplanes that meet these criteria and are leased to foreign airlines are also subject to the return provisions of paragraph (e) of this section.
- (c) The airplane complies with Stage 2 noise levels, is owned by a non-U.S. person, and is the subject of a binding lease to a U.S. person effective before and on September 25, 1991. Any such airplane may be operated for the term of the lease in effect on that date, and any extensions thereof provided for in that lease.
- (d) The airplane complies with Stage 2 noise levels and is operated by a foreign air carrier.
- (e) The airplane complies with Stage 2 noise levels and is operated by a foreign operator other than for the purpose of foreign air commerce.
- (f) The airplane complies with Stage 2 noise levels and—
- (1) On November 5, 1990, was owned by:
- (i) A corporation, trust, or partnership organized under the laws of the United States or any State (including individual States, territories, possessions, and the District of Columbia);
- (ii) An individual who is a citizen of the United States; or
- (iii) An entity owned or controlled by a corporation, trust, partnership, or individual described in paragraph (f)(1) (i) or (ii) of this section; and
- (2) Enters into the United States not later than 6 months after the expiration of a lease agreement (including any extensions thereof) between an owner described in paragraph (f)(1) of this section and a foreign airline.
- (g) The airplane complies with Stage 2 noise levels and was purchased by the importer under a written contract executed before November 5, 1990.
- (h) Any Stage 2 airplane described in this section is eligible for operation in