

SDARS AND DBS

EAS equipment requirement	SDARS	DBS
EAS decoder ¹	Y	Y
EAS encoder	Y	Y
Audio message on all channels ²	Y	Y
Video message on all channels ²	N/A	Y

¹EAS Participants may comply with the obligations set forth in § 11.56 to decode and convert CAP-formatted messages into EAS Protocol-compliant messages by deploying an Intermediary Device, as specified in § 11.56(b).

²All SDARS and DBS providers may comply with this requirement by providing a means to switch all programmed channels to a predesignated channel that carries the required audio and video EAS messages or by any other method that ensures that viewers of all channels receive the EAS message.

(b) Analog class D non-commercial educational FM stations as defined in § 73.506 of this chapter, digital class D non-commercial educational FM stations, analog LPFM stations as defined in §§ 73.811 and 73.853 of this chapter, digital LPFM stations, analog LPTV stations as defined in § 74.701(f), and digital LPTV stations as defined in § 74.701(k) of this chapter are not required to comply with § 11.32. Analog and digital LPTV stations that operate as television broadcast translator stations, as defined in § 74.701(b) of this chapter, are not required to comply with the requirements of this part. FM broadcast booster stations as defined in § 74.1201(f) of this chapter and FM translator stations as defined in § 74.1201(a) of this chapter which entirely rebroadcast the programming of other local FM broadcast stations are not required to comply with the requirements of this part. International broadcast stations as defined in § 73.701 of this chapter are not required to comply with the requirements of this part. Analog and digital broadcast stations that operate as satellites or repeaters of a hub station (or common studio or control point if there is no hub station) and rebroadcast 100 percent of the programming of the hub station (or common studio or control point) may satisfy the requirements of this part through the use of a single set of EAS equipment at the hub station (or common studio or control point) which complies with §§ 11.32 and 11.33.

(c) For purposes of the EAS, Broadband Radio Service (BRS) and Educational Broadband Service (EBS) stations operated as part of wireless cable systems in accordance with subpart M of part 27 of this chapter are defined as follows:

(1) A “wireless cable system” is a collection of channels in the BRS or EBS used to provide video programming services to subscribers. The channels may be licensed to or leased by the wireless cable system operator.

(2) A “wireless cable operator” is the entity that has acquired the right to use the channels of a wireless cable system for transmission of programming to subscribers.

(d) Local franchise authorities may use any EAS codes authorized by the FCC in any agreements.

(e) Other technologies and public service providers, such as low earth orbiting satellites, that wish to participate in the EAS may contact the FCC’s Public Safety and Homeland Security Bureau or their State Emergency Communications Committee for information and guidance.

[63 FR 29662, June 1, 1998, as amended at 65 FR 7639, Feb. 15, 2000; 65 FR 21657, Apr. 24, 2000; 65 FR 30001, May 10, 2000; 65 FR 34406, May 30, 2000; 67 FR 18506, Apr. 16, 2002; 69 FR 72031, Dec. 10, 2004; 70 FR 19315, Apr. 13, 2005; 70 FR 71031, Nov. 25, 2005; 71 FR 76220, Dec. 20, 2006; 72 FR 62132, Nov. 2, 2007; 77 FR 16699, Mar. 22, 2012]

§§ 11.12–11.14 [Reserved]

§ 11.15 EAS Operating Handbook.

The EAS Operating Handbook states in summary form the actions to be taken by personnel at EAS Participant facilities upon receipt of an EAN, an EAT, tests, or State and Local Area alerts. It is issued by the FCC and contains instructions for the above situations. A copy of the Handbook must be located at normal duty positions or EAS equipment locations when an operator is required to be on duty and be

§ 11.16

immediately available to staff responsible for authenticating messages and initiating actions.

[70 FR 71033, Nov. 25, 2005]

§ 11.16 National Control Point Procedures.

The National Control Point Procedures are written instructions issued by the FCC to national level EAS control points. The procedures are divided into sections as follows:

(a) *National Level EAS Activation*. This section contains the activation and termination instructions for the National Emergency Message.

(b) *EAS Test Transmissions*. This section contains the instructions for testing the EAS at the National level.

[59 FR 67092, Dec. 28, 1994, as amended at 67 FR 18508, Apr. 16, 2002; 87 FR 67823, Nov. 10, 2022]

§ 11.18 EAS Designations.

(a) A Primary Entry Point (PEP) is a private or commercial radio broadcast station that cooperatively participates with FEMA to provide EAS alerts to the public. PEPs are the primary source of initial broadcast for a Presidential Alert. A PEP is equipped with back-up communications equipment and power generators designed to enable it to continue broadcasting information to the public during and after disasters of national significance. The National Public Warning System (formerly called the Primary Entry Point System) is a nationwide network of broadcast stations and satellite operators used to distribute EAS alerts formatted in the EAS Protocol. FEMA is responsible for designating broadcast stations as PEPs.

(b) A National Primary (NP) is an entity tasked with the primary responsibility of receiving the National Emergency Message from a PEP and delivering it to an individual state or portion of a state. In states without a PEP, the NP is responsible for receiving the National Emergency Message from an out-of-state PEP and transmitting it to the public and other EAS Participants in the state. Multiple entities may be charged with primary responsibility for delivering the National Emergency Message.

47 CFR Ch. I (10–1–23 Edition)

(c) A State Primary (SP) is an entity tasked with initiating the delivery of EAS alerts other than the National Emergency Message.

(d) A State Relay (SR) is an entity not otherwise designated that is charged with retransmitting EAS alerts for the purpose of being monitored by a Local Primary or Participating National. SRs must monitor or deliver EAS alerts as required by the State EAS Plan.

(e) A State Relay Network (SRN) is a network composed of State Relay (SR) sources, leased common carrier communications facilities, or any other available communication facilities. The network distributes State EAS messages originated by the Governor or designated official. In addition to EAS monitoring, satellites, microwave, FM subcarrier, or any other communications technology may be used to distribute State emergency messages.

(f) A Local Primary (LP) is an entity that serves as a monitoring assignment for other EAS Participants within the state. LP sources may be assigned numbers (e.g., LP-1, 2, 3) and are relied on as monitoring sources by other EAS Participants in the Local Area. An LP may monitor any other station, including another LP, as set forth in the State EAS Plan, so long as doing so avoids creating a single point of failure in the alert distribution hierarchy.

(g) A Participating National (PN) is an EAS Participant that transmits national, state, or Local Area EAS messages, and is not otherwise designated within the State EAS Plan. PNs monitor LPs or other sources as set forth in the State EAS Plan.

[87 FR 67823, Nov. 10, 2022]

§ 11.20 [Reserved]

§ 11.21 State and Local Area plans and FCC Mapbook.

EAS plans contain guidelines which must be followed by EAS Participants' personnel, emergency officials, and National Weather Service (NWS) personnel to activate the EAS. The plans include the EAS header codes and messages that will be transmitted by key EAS sources (NP, LP, SP and SR). State and local plans contain unique methods of EAS message distribution