

Federal Communications Commission

§ 11.18

§ 11.13 Emergency Action Notification (EAN) and Emergency Action Termination (EAT).

(a) The Emergency Action Notification (EAN) is the notice to all broadcast stations, cable systems and wireless cable systems, other regulated services of the FCC, participating industry entities, and to the general public that the EAS has been activated for a national emergency.

(b) The Emergency Action Termination (EAT) is the notice to all broadcast stations, cable systems and wireless cable systems, other regulated services of the FCC, participating industry entities, and to the general public that the EAN has terminated.

[63 FR 29663, June 1, 1998]

§ 11.14 EAN Network and Primary Entry Point (PEP) System.

(a) The EAN network is a dedicated communications service connecting industry networks, wire services and common carriers with government activation points. It is used to distribute EAN and EAT messages. The industry control locations retransmit the EAN message, the Presidential message, and the EAT message on their facilities to their affiliates.

(b) The PEP system is a nationwide network of broadcast stations connected with government activation points. It can also be used to distribute EAN and EAT.

§ 11.15 EAS Operating Handbook.

The EAS Operating Handbook states in summary form the actions to be taken by personnel at broadcast stations, cable systems and wireless cable systems, and other participating entities upon receipt of an EAN, an EAT, tests, or State and Local Area alerts. It is issued by the FCC and contains instructions for the above situations. A copy of the Handbook must be located at normal duty positions or EAS equipment locations when an operator is required to be on duty and be immediately available to staff responsible for authenticating messages and initiating actions.

[63 FR 29663, June 1, 1998]

§ 11.16 National Control Point Procedures.

The National Control Point Procedures are written instructions issued by the FCC to national level EAS control points. They are for use by the participating radio and television networks, cable networks and program suppliers, common carriers and wire services. The procedures are divided into sections as follows:

(a) National Level EAS Activation. This section contains the activation and termination instructions for Presidential messages.

(b) EAS Test Transmissions. This section contains the instructions for testing the EAS at the National level.

(c) National Information Center (NIC). This section contains instructions for distributing United States Government official information messages after completion of the National Level EAS activation and termination actions.

§ 11.18 EAS Designations.

(a) National Primary (NP) is a source of EAS Presidential messages.

(b) Local Primary (LP) is a source of EAS Local Area messages. An LP source is responsible for coordinating the carriage of common emergency messages from sources such as the National Weather Service or local emergency management offices as specified in its EAS Local Area Plan. If it is unable to carry out this function, other LP sources in the Local Area may be assigned the responsibility as indicated in State and Local Area Plans. LP sources are assigned numbers (LP-1, 2, 3, etc.) in the sequence they are to be monitored by other broadcast stations in the Local Area.

(c) State Primary (SP) is a source of EAS State messages. These messages can originate from the Governor or a designated representative in the State Emergency Operating Center (EOC) or State Capital. Messages are sent via the State Relay Network.

(d) State Relay (SR) is a source of EAS State messages. It is part of the State Relay Network and relays National and State common emergency messages into Local Areas.

(e) Participating National (PN) sources transmit EAS National, State

§ 11.19

or Local Area messages. The EAS transmissions of PN sources are intended for direct public reception.

(f) Non-participating National (NN) sources have elected not to participate in the National level EAS and hold an authorization letter to that effect. Upon activation of the national level EAS, NN sources are required to broadcast the EAS codes, Attention Signal, the sign-off announcement in the EAS Operating Handbook and then stop operating. All NN sources are required to comply with §11.51, 11.52 and 11.61. They may transmit EAS State or Local Area messages at any time without prior notice.

§ 11.19 EAS Non-participating National Authorization Letter.

This authorization letter is issued by the FCC to broadcast station licensees and cable systems and wireless cable systems. It states that the licensee, cable operator or wireless cable operator has agreed to go off the air or in the case of cable discontinue programming on all channels during a national level EAS message. For Broadcast licensees this authorization will remain in effect through the period of the initial license and subsequent renewals from the time of issuance unless returned by the holder or suspended, modified or withdrawn by the Commission.

[63 FR 29663, June 1, 1998]

§ 11.20 State Relay Network.

This network is composed of State Relay (SR) sources, leased common carrier communications facilities or any other available communication facilities. The network distributes State EAS messages originated by the Governor or designated official. In addition to EAS monitoring, satellites, microwave, FM subcarrier or any other communications technology may be used to distribute State emergency messages.

§ 11.21 State and Local Area Plans and FCC Mapbook.

EAS plans contain guidelines which must be followed by broadcast and cable personnel, emergency officials and National Weather Service (NWS) personnel to activate the EAS. The

47 CFR Ch. I (10-1-00 Edition)

plans include the EAS header codes and messages that will be transmitted by key EAS sources (NP, LP, SP and SR). State and local plans contain unique methods of EAS message distribution such as the use of RBDS. The plans must be reviewed and approved by the Chief, Technical and Public Safety Division, Enforcement Bureau, prior to implementation to ensure that they are consistent with national plans, FCC regulations, and EAS operation.

(a) The State plan contains procedures for State emergency management and other State officials, the NWS, and broadcast and cable personnel to transmit emergency information to the public during a State emergency using the EAS.

(b) The Local Area plan contains procedures for local officials or the NWS to transmit emergency information to the public during a local emergency using the EAS. Local plans may be a part of the State plan. A Local Area is a geographical area of contiguous communities or counties that may include more than one state.

(c) The FCC Mapbook is based on the above plans. It organizes all broadcast stations and cable systems according to their State, EAS Local Area and EAS designation.

[59 FR 67092, Dec. 28, 1994, as amended at 60 FR 55999, Nov. 6, 1995; 63 FR 29663, June 1, 1998; 65 FR 21658, Apr. 24, 2000]

Subpart B—Equipment Requirements

§ 11.31 EAS protocol.

(a) The EAS uses a four part message for an emergency activation of the EAS. The four parts are: Preamble and EAS Header Codes; audio Attention Signal; message; and, Preamble and EAS End Of Message (EOM) Codes.

(1) The Preamble and EAS Codes must use Audio Frequency Shift Keying at a rate of 520.83 bits per second to transmit the codes. Mark frequency is 2083.3 Hz and space frequency is 1562.5 Hz. Mark and space time must be 1.92 milliseconds. Characters are ASCII seven bit characters as defined in ANSI X3.4-1977 ending with an eighth null bit (either 0 or 1) to constitute a full eight-bit byte.